

WATERPROOFING SLOPED AREAS

1. Place all waterproofing sheets parallel to slope; cap sheet pattern only.
2. Place all Laurenco Protection Course parallel to slope.
3. Place all protection course in a stacked brick pattern with vertical joints centered over previous sheets.
4. Firmly embed all sheets and protection course in adhesive.

LAURENCO
PROTECTION
COURSE LAID
BUTT JOINT

2 PLYS WATERPROOFING
SHEETS AND ADHESIVE.

