

Use only 1"X2'X4' panels of 1 lb. density polystyrene bead board
Or 1" X 2' X 4' panels of extruded polystyrene board
adhered in wet adhesive. Score the outside of the panels
to relieve surface tension and obtain conformance to the
walls. Lay tight butt joint in a brick pattern or insulation as specified

