

## STEP 1

NOTE; ASPHALTIC PROTECTION BOARDS CAN NOT BE USED WITHOUT PRIOR WRITTEN

ACCEPTANCE FROM THE LAURENCO TECHNICAL DEPARTMENT. ALL ASPHALTIC PROTECTION BOARDS ARE EXCLUDED FROM LAURENCO WARRANTIES.

NOTE: Wale can be in different angles but the same practice is used.

Keep Asphaltic Protection  
Below below Wale 1'

Pour or Shotcrete  
at least 6" below  
the Top of the  
Second ply of W/P

### ADHESIVE QUANTITIES

1. 2 to 2-1/2 gals.\* to Protection Course Wall.
2. 1/2 gals.\* for laps
3. See specification V-1.

\* All gallonage is approximate and based on averages and is per 100 SQ. FT.

DSM Wall

"H" Pile

Wale

Keep W/P  
below Top  
Edge of  
Protection  
Course.

Next lift of sheet.  
Work off of shaffold.

First ply

4 in. overlap of previous  
lift.

Second ply