

1" Thick Polystyrene Insulation adhered in wet adhesive. Score the outside of the panels to relieve surface tension and obtain conformance to the walls. Lay tight butt joint in a brick pattern.

2 PLY Laurenco System Waterproofing Sheets with Adhesive.

2 PLY Laurenco Sheet & Adhesive as 9" Wide Flashing Strips

LAURENCO PROTECTION COURSE.

