



NOTES:

1. FLASHING SIMILAR ALL AROUND DRAIN.
2. CHECK DRAIN LINES BEFORE STARTING WORK. NOTIFY OWNER IF BLOCKAGE IS OBSERVED OR IF DRAIN IS DAMAGED. CLEAR BLOCKED LINES AS AUTHORIZED.
3. REPLACE BROKEN/MISSING STRAINERS, CLAMP RINGS, BOLTS OR OTHER MISCELLANEOUS HARDWARE, AS NEEDED.
4. DRAIN BODY MUST BE PROPERLY PREPARED TO RECEIVE LAURENCO PMMA SYSTEM
CHECK WITH LAURENCO TECHNICAL DEPARTMENT FOR DRAIN PREPARATION REQUIREMENTS.