

FOR WATERPROOFING AROUND H-COLUMNS; APPLY FLASHINGS FIRST THEN APPLY THE HORIZONTAL FIELD SHEETS UP TO THE SIDES OF THE COLUMN. WHEN IT IS REQUIRED TO CAST DIRECTLY TO WATERPROOFING USE LAURENCO PROTECTION COURSE, AS A BARRIER AT THE INTERFACE BETWEEN THE WATERPROOFING AND THE CONCRETE BOTH HORIZONTALLY AND VERTICALLY.

FOLLOW THE DIRECTIONS ON THE FOLLOWING PAGES FOR THE FLASHINGS. THIS IS WHAT YOUR COMPLETED FLASHING SHOULD LOOK LIKE.

