



NOTE:

1. COMPLETE THE INSTALLATION OF THE FLASHINGS FIRST.
2. CUT ALL FIELD PLIES AND PROTECTION COURSE TO FIT TIGHTLY AROUND ENTIRE PERIMETER OF EACH PENETRATION.

NOTE 2: PENETRATIONS SPACING SHALL BE IN COMPLIANCE WITH THE NRCA WATERPROOFING MANUAL AND DETAILS SPECIFICALLY NRCA DETAIL WP-33

NOTE 3: LAURENCO PMMA FLASHING SYSTEM MAY BE UTILIZED IN LIEU OF MEMBRANE FLASHING. CHECK WITH LAURENCO TECHNICAL DEPARTMENT FOR PREPARATION REQUIREMENTS.