



INSTALL 2 PLY LAURENCO SHEET & ADHESIVE OVER CONCRETE PATCH EXTENDING OUT 4" FOR THE 1ST PLY & 8" FOR THE 2ND PLY ONTO THE EXISTING WATERPROOFING.

FILL IN BOX OUT WITH THE SPECIFIED CONCRETE OR HYDRAULIC CEMENT.

FOLD ANY REMAINING MATERIAL OVER PIPE PATCH.

REMOVE PIPE AND FILL HOLE WITH HYDRAULIC CEMENT