

## NOTE:

- 1. COMPLETE THE INSTALLATION OF THE MAIN FIELD SHEETS FIRST.
- 2. CUT ALL FIELD PLIES AND PROTECTION COURSE TO FIT TIGHTLY AROUND ENTIRE PERIMETER OF EACH PENETRATION.
- 3. PENETRATIONS TO BE PLACED A MINIMUM 12" APART AND A MINIMUM 12" FROM WALLS AND CURBS.