



NOTES:

1. FLASHING SIMILAR ALL AROUND DRAIN.
2. CHECK DRAIN LINES BEFORE STARTING WORK. NOTIFY OWNER IF BLOCKAGE IS OBSERVED OR IF DRAIN IS DAMAGED. CLEAR BLOCKED LINES AS AUTHORIZED.
3. REPLACE BROKEN/MISSING STRAINERS, CLAMP RINGS, BOLTS OR OTHER MISCELLANEOUS HARDWARE, AS NEEDED.
4. DRAIN BOWL & FLANGE MUST BE PROPERLY PREPARED TO ACCEPT LAURENCO PMMA FLASHING.
5. LAURENCO PMMA FLASHING RESIN MUST BE EXTENDED A MINIMUM 1/4" BEYOND LAURENCO FLEECE.