



NOTES:

1. LAURENCO PMMA RESIN MUST EXTEND A MINIMUM OF 1/4" BEYOND LAURENCO FLEECE.
2. FLASHING SIMILAR ALL AROUND DRAIN.
3. CHECK DRAIN LINES BEFORE STARTING WORK. NOTIFY OWNER IF BLOCKAGE IS OBSERVED OR IF DRAIN IS DAMAGED. CLEAR BLOCKED LINES AS AUTHORIZED.
4. REPLACE BROKEN/MISSING STRAINERS, CLAMP RINGS, BOLTS OR OTHER MISCELLANEOUS HARDWARE, AS NEEDED.