

Use 1"X2'X4' panels of 1 lb. density polystyrene bead board adhered in wet adhesive. Score the outside of the panels to relieve surface tension and obtain conformance to the walls. Lay tight butt joint in a brick pattern or insulation specified

Laurenco specification
V-1, 2 plies
Waterproofing Sheet with
Adhesive.

For lifts greater
than 1 ft. use
polystyrene bead
board instead of
LAURENCO
protection Course.

2" typ.

CONCRETE OR C.M.U.— with
flush mortar joints

1/8" LAURENCO
PROTECTION COURSE

Wear slab (reinforced)

4"
12" max

COMPACTED FILL 95% min.

LAURENCO PREMIUM
PROTECTION COURSE
OR LAURENCO
APPROVED ALTERNATE

2 PLIES WATERPROOFING SHEET
Adhered to protection course.
Do not top coat top ply of
waterproofing sheet.