

## NOTE:

- 1. DRAIN BOWL AND FLANGE MUST BE PROPERLY PREPARED TO ACCEPT LAURENCO PMMA. PLEASE CHECK WITH LAURENCO TECHNICAL DEPARTMENT FOR PROPER PREPARATION PROCEDURES.
- 2. LAURENCO PMMA RESIN MUST EXTEND A MINIMUM  $\frac{1}{4}$ " BEYOND LAURENCO FLEECE.
- 3. FOR EXPOSED APPLICATIONS LAURENCO G CAP OR G FR CAP MAY BE SUBSTITUTED FOR THE LAURENCO PROTECTION COURSE.

