


APPLICATION OF FIELD FLASHING


****NOTE: VIEWS OF PREVIOUS STEPS OMITTED FOR CLARITY**



STEP 11: CUT A PIECE OF WATERPROOFING SHEET THAT IS 9" WIDE AND LONG ENOUGH TO REACH, BUT DOES NOT EXTEND AROUND THE NEXT CORNER. IF THE DISTANCE IS GREATER THAN YOU CAN EASILY APPLY YOU MAY USE SHORTER PIECES WITH A 4" LAP ON EACH PIECE. YOU WILL NEED TWO PLIES ON EACH FACE OF THE PENETRATION..

FOLD EACH SHEET WITH 4" AND 5" SIDES, DOWN THE LONG AXIS.

THE FIRST PLY OF FIELD FLASHINGS WILL BE APPLIED WITH THE 5" SIDE ON THE VERTICAL AND THE 4" SIDE ON THE HORIZONTAL. TOP COAT LIGHTLY WITH ADHESIVE.



STEP 12: PLACE THE SECOND PLY OF FIELD FLASHING WITH THE 4" SIDE UP THE VERTICAL AND THE 5" SIDE ONTO THE HORIZONTAL. TOP COAT LIGHTLY WITH ADHESIVE.

SECOND PLY
FIELD FLASHING

NOTE 1: DO NOT ROUND CORNERS. DO NOT "BRIDGE" CORNERS. ALWAYS FIT MATERIAL TIGHTLY.

NOTE 2: LAURENCO PMMA LIQUID FLASHING MAY BE UTILIZED IN LIEU OF MEMBRANE FLASHING.